

INTENSITY SENSOR REPLACE MANUAL

1.Disconnect Intensity NUT from uv unit



2.Disconnect the old transmitter from cable



3. REPLACE INTENSITY SENSOR with new one and reassemble



TEMP. SENSOR REPLACE MANUAL

******Must be drain uv unit before disconnect a sensor******

1.OPEN the cap and disconnect a cable



2. Disconnect a temp. sensor



3. REPLACE temp sensor with new one and reassemble



LEVEL3000 SENSOR REPLACE MANUAL

1.Close the valve



2.Disconnect the old transmitter from isolating valve.



3. Find a pressure transmitter cable at Filter JUNCTION BOX



4. Disconnect a cable by using setting driver



5. REPLACE LEVEL 3000 with new one

